



HD-15642

Toilet Partition Installation Manual

PHONE: 1-866-820-3579

FAX: 1-866-317-2786

ATTENTION

DO NOT MIX
FASTENER PACKS

**EACH FASTENER PACK HAS THE NECESSARY
BOLTS, BARRELS AND SCREWS TO INSTALL
THE RESPECTIVE PANEL, PILASTER OR DOOR.**







**TORX HEAD BITS ARE PACKED IN THE EXTRA
FASTENER PACKS.**

TABLE OF CONTENTS

<u>STEP</u>		<u>PAGE</u>
1	TOOLS REQUIRED	4
2	GETTING STARTED	5
3	MARK THE PARTITION LAYOUT	6
4	INSTALL THE PANELS	8
5	INSTALL THE WALL PILASTER.....	10
5A	USING LEVELING DEVICES.....	10
5B	USING STAINLESS STEEL SHOE & HEEL.....	12
5C	USING POLY SHOES.....	14
6	INSTALL THE PILASTERS.....	16
8	ATTACH THE DOORS	20
9	ATTACH THE DOOR HARDWARE	22
10	ADJUSTABLE ALUMINUM PILASTERS	24
11	BOLT AND BARREL SIZES	25

1 TOOLS REQUIRED

- TAPE MEASURE
- 4 FOOT LEVEL
- RATCHET TYPE BIT DRIVER (torx head bits supplied)
- FLAT HEAD SCREWDRIVER
- PHILLIPS HEAD SCREWDRIVER
- 1 WAY SCREWDRIVER
- TWO 9/16" OPEN END WRENCHES
- HAMMER
- TWO 14" BLOCKS
- DRILL
- ROTARY HAMMER DRILL
- HACKSAW
- 5/16" CARBIDE TIPPED HAMMER DRILL BIT
- 5/8" CARBIDE TIPPED HAMMER DRILL BIT
- 1/4" HIGH SPEED STEEL DRILL BITS
- 1/8" HIGH SPEED STEEL DRILL BITS
- CHALK BOX



FA-901	3/4" BOLT	
FA-110	1-1/2" BOLT	
FA-806	3/4" SCREW	
FA-952	15/16" BARREL	
FA-801	1-1/2" SCREW	
FA-400	PLASTIC ANCHOR	
FIGURE 11 FASTENER DETAIL		

2 GETTING STARTED

- 2.1 Find the packing list in the box marked “Packing List”
- 2.2 Check delivered materials and make sure no parts are damaged or missing.
- 2.3 Check dimensions in each bathroom against the shop drawings marked “For Field Use”. Make notes of differences.
- 2.4 Clear bathrooms to provide workroom.


3 MARK THE PARTITION LAYOUT

- 3.1 Establish and mark the center of the panels across the back wall according to shop drawings. For end-panels and alcove-panels mark the outer edge. (See fig.3.1)
- 3.2 Establish and mark the panel-brackets on the back wall 18", and 65" from the finished floor.
- 3.3 Establish and mark the wall-pilaster location on the side wall according to shop drawings. (See fig.3.1)
- 3.4 Establish and mark the pilaster-brackets on the side wall 18", and 65" from the finished floor.
- 3.5 Establish and mark the outer edges of each pilaster from the back and side walls according to shop drawings. (See fig.3.1)
- 3.6 Mark and drill holes for the floor fasteners.
 - 3.6.1 For leveling devices mark 5/8" in from the end of the pilaster(s), centered from front to back. Drill a 2" deep hole in the floor with a 5/8" bit.
 - 3.6.2 For shoe & heel place the heel (shoe) on the floor centered between the outer edges of the pilaster with the heel facing the back wall. Using the heel (shoe) as a template, mark the holes. Drill a 2" deep hole in the floor with a 5/16" bit. (See fig.5-B.2 or fig.5-C.1)
- 3.7 Mark wall bracket mounting holes using the brackets as a template. Center and level the brackets before marking (See fig.3.1). For end-panels use the outer edge.
- 3.8 Drill 5/16" holes for wall brackets.
- 3.9 Insert plastic anchors (FA-400) into holes.
- 3.10 Secure wall and pilaster brackets with 1½" stainless steel screws (FA-801). (See fig.3.2)



4 INSTALL THE PANELS

- 4.1 Place a 14" high support in position to hold up the panels.
(see fig. 4.1)
- 4.2 Set the panel on the support and slide the panel into the wall brackets until the bottom is 1/2" from the wall.
- 4.3 Drill the bottom bracket hole through the panel with a 1/4" drill bit and secure with a 3/4" bolt (FA-901) and a 15/16" barrel (FA-951).
- 4.4 Level the top of panel.
- 4.5 Drill the top bracket hole with a 1/4" drill bit and secure with a 3/4" bolt (FA-901) and a 15/16" barrel (FA-952).
- 4.6 Drill the remaining bracket holes with a 1/4" drill bit and secure with a 3/4" bolt (FA-901) and a 15/16" barrel (FA-952).
- 4.7 Repeat steps 4.1 through 4.5 for each panel.





**FIGURE 4.1
PANEL INSTALLATION**

5 INSTALL THE WALL PILASTER

5A USING LEVELING DEVICES


- 5A.1 Place a lead anchor into the floor holes from step 3.6.
- 5A.2 Screw a 3/8" x 3½" threaded rod into the lead anchor. Place a 3/8" flat washer and 3/8" nut onto the rod and tighten with a 9/16" wrench to secure the lead anchor.
- 5A.3 Place a second 3/8" nut and 3/8" flat washer onto the threaded rod. Move the nut half way down the rod. (See figure 5A.1)
- 5A.4 Place the wall-pilaster onto the threaded rod and slide it into the wall mounted pilaster-brackets.
- 5A.5 Adjust the 3/8" nut to raise (lower) the pilaster. (See figure 5A.1)
- 5A.6 Place a piece of headrail on top of pilaster and mark the sides and bottom of the headrail on the wall. (See figure 5A.2)
- 5A.7 Remove the pilaster. Using the headrail bracket as a template, mark and drill the headrail bracket holes in the wall. The hole on the side of the bracket should be on the bottom.
- 5A.8 Mount the headrail bracket to the wall using 1½" stainless steel screws (FA-801).
- 5A.9 Place the pilaster shoe onto the pilaster and place the pilaster onto the threaded rod. Place a third washer and nut onto the threaded rod.
- 5A.10 Set the bottom gap between the wall and the pilaster according to the shop drawings. Tighten the top nut to secure the pilaster.
- 5A.11 Level the pilaster. Drill the top pilaster bracket hole with a ¼" drill bit. Secure with a 3/4" bolt (FA-901) and a 15/16" barrel (FA-952).
- 5A.12 Drill the bottom bracket holes. Secure with bolts and barrels.
- 5A.13 Drill through the shoe and pilaster. Secure with a ¾" bolt (FA-901) and a 15/16" barrel (FA-952).




5 INSTALL THE WALL PILASTER

5B USING STAINLESS STEEL SHOE & HEEL

- 5B.1 Mount the heel to the floor with 1½" stainless steel screws (FA-801). The upright part of the heel should be nearest the back wall. (See figure 5B.1)
- 5B.2 Place the pilaster onto the heel and slide the wall-pilaster into the wall brackets. (See figure 5B.2)
- 5B.3 Adjust leveling bolt to raise (lower) the pilaster.
- 5B.4 Place a piece of headrail on top of the pilaster. Mark the sides and bottom of the headrail onto the wall.
- 5B.5 Remove the pilaster. Using the headrail bracket as a template, mark the mounting holes for the bracket. The side holes of the mounting bracket should be on bottom.
- 5B.6 Mount the headrail bracket to the wall using 1½" stainless steel screws (FA-801)
- 5B.7 Place the shoe onto the pilaster and place the pilaster onto the heel. Slide the pilaster into the wall brackets. (See figure 5B.1)
- 5B.8 Set the bottom gap between the wall and the pilaster according to shop drawings.
- 5B.9 Drill the bottom bracket hole through the pilaster with a ¼" drill bit. Secure with a ¾" bolt (FA-901) and a 15/16" barrel. (FA-952)
- 5B.10 Check level and drill the top bracket hole through the pilaster with a ¼" drill bit. Secure with a ¾" bolt (FA-901) and a 15/16" barrel. (FA-952)
- 5B.11 Drill ¼" hole(s) through the shoe, heel and pilaster. Secure the shoe with ¾" bolts (FA-901) and 15/16" barrels. (FA-952)



**FIGURE 5B.1
STAINLESS STEEL SHOE & HEEL ANCHORAGE**





**FIGURE 5B.2
PILASTER TO WALL DETAIL**

5 INSTALL THE WALL PILASTER


5C USING POLY SHOES

- 5C.1 Mount the shoe to the floor with 1½” stainless steel screws (FA-801). (See figure 5C.1)
- 5C.2 Place the pilaster into the shoe and slide the wall-pilaster into the wall brackets. (See figure 5B.2)
- 5C.3 Adjust leveling bolt to raise (lower) the pilaster.
- 5C.4 Place a piece of headrail on top of the pilaster. Mark the sides and bottom of the headrail onto the wall.
- 5C.5 Remove the pilaster. Using the headrail bracket as a template, mark the mounting holes for the bracket. The side holes of the mounting bracket should be on bottom.
- 5C.6 Mount the headrail bracket to the wall using 1½” stainless steel screws (FA-801)
- 5C.7 Slide the pilaster into the shoe. Slide the pilaster into the wall brackets. (See figure 5B.1)
- 5C.8 Set the bottom gap between the wall and the pilaster according to shop drawings.
- 5C.9 Drill the bottom bracket hole through the pilaster with a ¼” drill bit. Secure with a ¾” bolt (FA-901) and a 15/16” barrel. (FA-952)
- 5C.10 Check level and drill the top bracket hole through the pilaster with a ¼” drill bit. Secure with a ¾” bolt (FA-901) and a 15/16” barrel. (FA-952)
- 5C.11 Drill through the shoe and the pilaster with a 3/16” drill bit. Secure with a ¾” screw (FA-806).




6 INSTALL THE PILASTERS

- 6.1 Prepare the pilaster floor fasteners. For leveling device follow steps 5A.1 through 5A.3. For shoe & heel follow step 5B.1 or 5C.1.
- 6.2 Place the pilaster onto the leveling device (or heel) and level the top of the pilaster with the pilaster at the wall.
- 6.3 On the back of the pilaster mark the center of the panel according to shop drawings. (See fig 6.2)
- 6.4 Mark the pilaster where the brackets will be located at 18" and 65" off the floor for shoe and heel and 17" and 64" for leveling device.
- 6.5 Place the pilaster-to-panel brackets onto the pilaster where the marks are made. Mark the mounting holes. (see fig 6.2)
- 6.6 Drill 3/16" holes into the pilaster and secure the pilaster-to-panel brackets with 3/4" screws (FA-806).
- 6.7 Place the shoe onto the pilaster and place the pilaster onto the leveling device (or heel). Slide the panel into the bracket.
- 6.8 Secure the pilaster.
 - 6.8.1 For leveling devices place a 3/8" washer and nut onto the threaded rods and tighten to secure the pilaster.
 - 6.8.2 For shoe & heel level top of pilaster with pilaster at wall, drill a 1/4" hole through the shoe, heel and the pilaster.
- 6.9 Level the pilaster front and drill through the top panel bracket hole. Secure the panel with a 3/4" bolt (FA-901) and 15/16" barrel. (FA-952). Drill and secure the remaining panel bracket holes.
- 6.10 Repeat steps 6.2 through 6.9 for each pilaster.
- 6.11 For leveling devices secure the shoes. Drill a 1/4" hole through the pilaster. Secure the shoes with 3/4" bolts (FA-901) and 15/16" barrels. (FA-952)



**FIGURE 6.1
PILASTER TO PANEL ATTACHMENT**

SEE SHOP DRAWINGS FOR DISTANCE BETWEEN
PILASTERS BEFORE FASTENING PILASTERS TO FLOOR.




**FIGURE 6.2
PILASTER BRACKET LOCATION**


7 INSTALL THE HEADRAIL

- 7.1 Measure and cut the front headrail to the appropriate length. For large openings, cut the headrail as long as possible with the cut in the center of a pilaster.
- 7.2 Lay the headrail on top of the pilasters and slide it into the headrail wall bracket(s).
- 7.3 Drill a 1/4" hole through the headrail bracket, headrail and the wall-pilaster. Secure with a 3/4" bolt (FA-901) and 15/16" barrel (FA-952).
- 7.4 For each pilaster, measure and mark the door opening width according to shop drawings. Drill a 3/16" hole into the headrail and the pilaster. Secure with a 3/4" screw (FA-806). See the notes to determine how many holes to drill.
- 7.5 For in-corner and free-standing configurations place an end-cap and a corner headrail bracket onto the end of the headrail. Drill a 1/4" hole through the headrail bracket, headrail and pilaster. Secure with a 3/4" bolt (FA-901) and 15/16" barrel (FA-952).
- 7.6 Measure from the top of the panel to the bottom of the corner headrail bracket.
- 7.7 Measure, mark and secure a headrail bracket on the wall at the height measured in step 7.6.
- 7.8 Measure from the back wall to the corner headrail bracket. Cut a piece of headrail to fit between the two brackets. Drill a 1/4" hole through the headrail and bracket and secure with 3/4" bolts (FA-901) and 15/16" barrels (FA-952).

Pilaster Size	# Screws	Location
< 7"	1	Centered
8" – 13"	2	2" from each end
> 14"	3	2" from each end and one centered



**FIGURE 7.1
HEADRAIL ATTACHMENT**




**FIGURE 7.2
HEADRAIL CORNER BRACKET**

8 ATTACH THE DOORS


- 8.1 Measure 2" from top of door to top of hinge. Drill holes with 1/4" drill bit. Secure part 2 of the top hinge onto the top of the door with 3/4" bolts (FA-901) and 15/16" barrels (FA-952). (See fig. 2)
- 8.2 Measure 2" from bottom of door to bottom of hinge. Drill holes with 1/4" drill bit. Secure part 4 of the bottom hinge onto the bottom of the door with 3/4" bolts (FA-901) and 15/16" barrels (FA-952). (See fig. 2)
- 8.3 Using a 14" block, set door into position with hinges and check that the door and panel are level. Drill the top pilaster hinge to pilaster using a 1/4" drill bit. Secure part 1 of the top hinge to the pilaster with 3/4" bolts (FA-901) and 15/16" barrels (FA-952). (See fig. 2)
- 8.4 Set part 3 of the bottom hinge onto the bottom of the pilaster and drill with a 1/4" drill bit with cardboard spacer intact. Remove spacer and secure with 3/4" bolts (FA-901) and 15/16" barrels (FA-952). (See fig. 2)
- 8.5 Please note all handicap doors receive a third hinge. Install in middle of door.

PLEASE NOTE:


**ALL WRAP AROUND ALUMINUM HINGES ARE REVERSIBLE.
TO REVERSE HINGES, PULL OUT INTERNAL PARTS FROM ONE END OF PART A AND
INSERT INTO THE OTHER END OF PART A.
REPEAT FOR PART B. (SEE DETAIL BELOW)**



**FIGURE 1
TOP HINGE DETAIL**



**FIGURE 2
HINGE DETAIL**



Notes:

- To increase or decrease the default door opening reposition the adjustable pin in the top hinge. The default position is 15° open.

9 ATTACH THE DOOR HARDWARE

9.1 Mark the keeper position on the Pilasters.

9.1.1 For surface mounted latches, measure and mark the center of the keeper 41" above the finished floor.

9.1.2 For recessed latches, mark the center of the keeper at the height of the oval hole on the door latch plunger.

9.2 Using the keeper as a template, mark and drill ¼" holes through the pilaster. Secure the keepers using ¾" bolts (FA-901) and 15/16" barrels (FA-952).

9.3 Mount the door latch. Position the surface mounted latches on the inside of the door so the latch clears the keeper when the door opens. Using the latch as a template, mark and drill ¼" holes through the door.

9.3.1 For inswing doors, secure the latch with ¾" bolts (FA-901) and 15/16" barrels (FA-952).

9.3.2 For outswing doors secure the latch to the door pull with 1-1/2" bolts (FA-110).


9.4 Mount the coat hook / bumper

9.4.1 For inswing doors place the coat hook / bumper 4" from the top and outer edge. Mark and pre-drill 1/8" holes in the door. (Do not drill all the way through). Secure the coat hook / bumper to the inside of the door with 5/8" screws (FA-305).

9.4.2 For outswing doors center the coat hook 4" from the top. Mark and pre-drill 1/8" holes in the door. (Do not drill all the way through). Secure the coat hook with 5/8" screws (FA-305).


9.4.3 For ADA doors see local specifications for coat hook placement. (usually 48" from the finished floor)

9.5 For recessed latches insert the pin into the small hole in the door. Insert the male piece of the recessed latch in door with the notch of the pin in the top pin of the male piece using plastic washers as needed. Insert the female piece and secure with a ½" bolt (FA-501) and a ¼" lock washer (LW-100). Insure that the thumb turn is on the inside of the door. For outswing doors attach the door pull beside the recessed latch with 1-3/6" bolts (FA-904).



Notes


- For ADA and emergency access doors mount the latch near the top of the keeper so that when in the latched position the door can be lifted and opened.



10 ADJUSTABLE ALUMINUM PILASTERS

INSTALLATION INSTRUCTIONS:



- MOUNT PIECE 'B' TO WALL
14" ABOVE FINISHED FLOOR.
- PLACE PIECE 'A' OVER PIECE 'B'
AND ADJUST TO PROPER WIDTH.
- DRILL FOR AND INSTALL THROUGH-BOLTS.



NOTE:
ADJUSTS
1-1/2" - 2-1/16"












3/4" - 1" ADJUSTABLE	
(7) 1-1/2" ANCHORS	FA-400
(7) 1-1/2" SCREWS	FA-801
(5) 3/4" BOLTS	FA-901
(5) 15/16" BARRELS	FA-952

NOTE: EA. 1" ADJUSTABLE PILASTER
RECEIVES THE ABOVE HOWE.



ADJUSTABLE ALUMINUM PILASTER
FIGURE 10.1

11 BOLT AND BARREL SIZES

<p>PILASTER BRACKETS</p> 	 <p>3/4" BOLT</p> <p>15/16" BARREL</p> <p>1" PILASTER</p>
<p>SHOES</p>	 <p>ST/ST SHOE</p> <p>15/16" BARREL</p> <p>PLASTIC SHOE</p> <p>1" PILASTER</p> <p>3/4" BOLT</p> <p>3/4" SCREW</p>
<p>PANEL BRACKETS</p> 	 <p>15/16" BARREL</p> <p>3/4" BOLT</p> <p>1" PANEL</p>
<p>PANEL TO PILASTER BRACKETS</p> 	 <p>1" PANEL</p> <p>3/4" SCREW</p> <p>1" PILASTER</p>
<p>ANGLE BRACKETS</p> 	 <p>15/16" BARREL</p> <p>3/4" BOLT</p> <p>1" POLY</p>
<p>HEADRAIL BRACKETS + HEADRAIL</p> 	 <p>3/4" SCREW</p> <p>15/16" BARREL</p> <p>3/4" BOLT</p> <p>HR TO WALL BRACKET</p> <p>CORNER HR BRACKET</p>



Phone: 1-866-820-3579

Fax: 1-866-317-2786

Copyright 2003